

POP **TC AIR**  
NANO+LED UVC



Flow air purifier

# TC AIR nano+led uvc

without a fan and filters inside.

Dedicated to use in the supply-exhaust units in malls, public facilities, cold stores and production halls.

Flow air purifier

# TC AiR nano+led uvc

without a fan and filters inside.

It is a device which combines the most advanced technologies which are used in order to fight viruses, bacteria, fungi and allergens.

The interior of the device is covered with TC Bacto Vir Shield nanocoating, **based on anti-bacterial coating with photocatalytic properties.** Under the influence of ultraviolet radiation, it is able to break down various chemical compounds into water, carbon dioxide and non-organic anions. The coating uses a catalyst in the form of titanium dioxide (nanoTiO<sub>2</sub>), the ability of light absorption of which are strengthened by silver atoms. As a result, our **anti-viral coatings TC Bacto Vir Shield**, in combination with UV-emitting devices, including UVC, give the effect of coating several times stronger. POP TC AiR (nano+ UVC LED) is designed to achieve the highest efficiency of operation, in a very economical way, closing the huge purifying potential in a small device.



**TC BACTO-VIR**  
- SHIELD -

Our modified nano VLR photocatalyst has an amazing effect on killing almost all types of bacteria and viruses including mutant forms such as MRSA, SARS, H5N1 etc. The performance of our antimicrobial coating is maintained for a very long time thanks to the catalytic reaction mode. Our improved photocatalyst can accurately break down bacteria, viruses into H<sub>2</sub>O and CO<sub>2</sub> as well as their endotoxins. The system based on self-cleaning guarantees effectiveness of operation, eliminating the accumulation of bacterial cells on the surface of the device (e.g. silver antibacterial process). While, the anti-microbial coating of the photocatalyst is also able to eliminate smoke and animal odour and indoor allergens, reducing the incidence of respiratory diseases.

# Step-by-step photocatalysis

Photocatalysis is a process that accelerates chemical reactions involving ultraviolet radiation. Titanium dioxide enriched with silver atoms acts as a semiconductor that knocks electrons out of the furthest valence shell. As a result, the electrons jump in TiO<sub>2</sub> from the baseband to the semiconductor band, where they can combine with oxygen to form active forms, namely the superoxide anion radical O<sub>2</sub><sup>-</sup>. After the electrons jump, positively charged electron holes are formed in titanium dioxide. As a result of combining them with water in the air, hydroxyl radicals are formed. Since they are deprived of one electron, they are characterized by high chemical activity and high ability to react with other compounds.

## Hydroxyl radicals combine with volatile organic compounds, including:

- ✓ polycyclic aromatic hydrocarbons (PAHs), e.g. benzo(a)pyrene, biphenyl or naphthalene, which are present in car exhaust fumes and with harmful nitrogen oxides.

Hydroxyl radicals lead to the decomposition of complex substances into simple compounds. The activity is extremely effective against viruses and bacteria. Our nanocoatings break down the microorganisms into water and carbon dioxide, which are substances that are safe for humans.

## The effectiveness of nanocoatings has been confirmed by tests at Eurovir Hygiene-Labor GmbH

EN 14476: 2019 methodology - efficiency without light  
4.62 log means  $1 - (0.1 \wedge 4.62) =$  a reduction of 99.998%

Nanocoatings are virucidal against all enveloped viruses - HIV, HBV, HCV, influenza viruses, corona viruses (including SARS-CoV-2) and others.

# Efficiency table

<b>Antimicrobial activity</b>			
Test organism	Office lighting conditions		
	Inoculum concentration (CFU/ml)	The value of bacteriostatic activity after 24h	Bacteriostatic value (%)
Staphylococcus aureus (MRSA) ATCC33591 Methicillin resistant staphylococcus aureus	1.1x10 <sup>5</sup>	>6.1	>99.9999%
Escherichia coli ATCC8739	1.7x10 <sup>5</sup>	>6.6	>99.99997%
Listeria monocytogenes 54001	2.7x10 <sup>5</sup>	>3.8	>99.98%
Legionella pneumophila ATCC33152	2.3x10 <sup>5</sup>	>5.2	>99.999%
Salmonella typhimurium AS.1.1194	1.3x10 <sup>5</sup>	>5.8	>99.9998%
Alpha Hemolytic Streptococcus CMCC 32213	1.2x10 <sup>5</sup>	>6.2	>99.9999%
Klebsiella pneumoniae ATCC 4352	2.9x10 <sup>5</sup>	>6.3	>99.9999%
ISO 20743:2013/JIS L1902:2008 Certified by SGS Grupe			
Results from the test on ceramic plate			
Test organism	Illuminated by a 40W fluorescent bulb during the test		
	0 Hour (cfu/ml)	24 hour (cfu/ml)	Bacteriostatic value (%)
Escherichia coli ATCC 25922	3.9x10 <sup>4</sup>	9.0x10 <sup>2</sup>	97.69
Staphylococcus aureus ATCC 6538	6.8x10 <sup>3</sup>	1.1x10 <sup>2</sup>	98.38
Pseudomonas aeruginosa ATCC 9027	2.8x10 <sup>5</sup>	84	99.97
Klebsiella pneumoniae	2.7x10 <sup>5</sup>	1.5x10 <sup>3</sup>	99.44
GB15979-2002 Certified by Guangdong National Microorganism Detection Center			
<b>Fungi</b>			
Aspergillus Niger ATCC 6275	2.3x10 <sup>5</sup>	>4.7	99.988
Antimicrobial activity under the influence of the various light intensities			
Tested microorganism Xanthomonas Perforans			
The intensity of the light		Bacteriostatic value in (%)	
30000 Lux		>99.99999%	
1200 Lux		>99.95%	
300 LUX		>99.9%	
No lighting		>65%	
<b>Viruses</b>			
Tested virus	The amount of virus		Reduction (%)
Vacciniavirus (Elstree)	6,95 +/- 0,39 ml		≥99,99
Transmissible Gastroenteritis Virus of Swine (TGEV, Toyama 36)	6,43 +/- 0,25 ml		≥99,99
Eurovir Hygiene-Labor GmbH metoda DIN EN 14476:2019			
Influenza A virus; A/PR/8/34 (H1N1) ATCC VR-1469	2.10 x 10 <sup>7</sup>		99.99
NQEC Nissenken Quality Evaluation Center, Tokyo ISO21702:2019			
<b>SARS-CoV-2</b>	1x10 <sup>7</sup>		99
Virology Research Services Ltd MRC LMBC, Gower Street, London			

# Efficiency table

Antimicrobial activity			
Test organism	Test /Norm	Action time in minutes	Microbicidal value (%)
Influenza type virus A H1N1	ISO 18184:2014 (E)	120 minutes	99,92
SGS -CSTC Technical Services Co.,Ltd.			
Modified Vaccina Ankara virus (MVA)	EN 14476:2019	10 minutes 30 minutes 60 minutes	>99,9 >99,99 >99,999
Eurovir Hygiene-Labor GmbH			
Polio virus	ISO 21702:2019	120 minutes	99,15
SGS -CSTC Technical Services Co.,Ltd.			
Human virus Coronavirus - 229E	ISO/IEC 17025:2017 Accreditation no. 111376	60 minutes Before the actual test, the coating was stress-tested-it was wiped 100 times with 70% ethanol	90
Human virus Coronavirus - 229E	ISO/IEC 17025:2017 Accreditation no. 111376	120 minutes Before the actual test, the coating was stress-tested-it was wiped 100 times with 70% ethanol	99,9
Virology Research Services Ltd MRC LMBC, Gower Street, London			
Escherichia coli ATCC 8739	ISO 22196:2011	120 minutes	99,96
SGS -CSTC Technical Services Co.,Ltd.			
Escherichia coli ATCC 8739	ISO22196:2011	60 minutes	99,13
SGS -CSTC Technical Services Co.,Ltd.			
Pseudomonas aeruginosa ATCC9027	ISO22196:2011	120 minutes	>99,99
SGS -CSTC Technical Services Co.,Ltd.			
Staphylococcus aureus ATCC 6538P	ISO22196:2011	120 minutes	>99,99
SGS -CSTC Technical Services Co.,Ltd.			
Escherichia coli ATCC 9739	ISO 22196:2011	One year after application	>99,9
Staphylococcus aureus ATCC 6538P	ISO 22196:2011	One year after application	>99,7
Pseudomonas aeruginosa ATCC 9027	ISO 22196:2011	One year after application	>99,9
Klebsiella pneumoniae ATCC 4352	ISO 22196:2011	One year after application	>99,9
Staphylococcus aureus ATCC 6538P	ISO 22196:2011	The surface covered with the coating, before the performance test in accordance with ISO 22196:2011, was brushed by us 5000 times in accordance with the ASTM D2486 method.	>99,9
SGS -CSTC Technical Services Co.,Ltd.			

# Latest generation disinfection

It is undeniable that in the near future LED technology will displace discharge sources of UV radiation, i.e. fluorescent lamps, quartz lamps and UV lamps from individual market sectors. Also, recently created as a result of the economic situation related to the COVID-19 pandemic, sterilizers based on the so-called excimer lamps, due to their size, appearance and cost of production, are not able to threaten the imminent domination of the disinfection industry by LED technology.

## What is the advantage of UVC LED over old-type artificial UVC radiation sources?

- ✓ no toxic mercury content
- ✓ more effective in fighting pathogens wavelength of light - narrower and more precise radiation range
- ✓ thanks to the small size - the possibility of implementing UV LED light sources in each type of light fixture and lamp, and the possibility of easy integration with electronic control systems
- ✓ possibility of precise control of the UVC radiation beam, allowing for calculating the radiation doses necessary for disinfection helps to increase the energy efficiency of the disinfection process and to avoid dynamic photodegradation of the irradiated materials
- ✓ no ozone production harmful to humans and animals - no need to ventilate the rooms after the disinfection process is completed
- ✓ longer service life of the UVC LED module, low operating costs - no need to periodically replace the radiatorst



# POP TC AIR

NANO+LED UVC

The TC AiR nano + led uvc flow air purifier is a combination of LED energy efficiency with advanced technology used in the fight against viruses, bacteria, fungi and allergens.

From now on, modern, elegant and professional equipment will guard the sterility of rooms and the health of users.

## Accuracy and reliability of operation

The effectiveness in inactivating viral and bacterial pathogens has been confirmed by research at the Department of Biotechnology and Food Microbiology at the University of Life Sciences in Wrocław.

Our UVC LED owes its effectiveness to many technical aspects. Thanks to the use of the highest quality UVC LEDs with a semiconductor chipset from a leading Korean manufacturer in the fixture, and thanks to the use of double-cleaned JGS-1 quartz lenses with the appropriate focus, we have created an LED module, which is an extremely effective weapon in the fight against viral and bacterial pathogens.

The carefully selected radiation power of the UVC LED module with a peak wavelength of 273 nm, causes dynamic destruction and inactivation of pathogenic microorganisms. UVC LED is a virucidal and bactericidal fixture, however, with the right time of irradiation (and the resulting dose of radiation), unicellular fungi, mould spores, protozoa, mites or algae are also destroyed. Thanks to the multi-point (coming from many individual fixtures) conical radiation emission, surfaces are decontaminated by rays reaching them at different angles, thus increasing the effectiveness of destroying pathogens located on them, which fall into the so-called 'cross-fire'.





# The UVC LED system is directed towards decontamination of indoor air.

The time required for effective surface disinfection ranges from 10 minutes to 6 hours and is specified in detail in each individual simulation delivered to the customer. The average time of the UVC disinfection process recommended by the UVC LED is 3 hours. It should be remembered that the time of air disinfection through which UVC radiation penetrates is much shorter. The effectiveness of fighting airborne pathogens, as a result of direct continuous ultraviolet radiation, is incomparably greater and more dynamic than the effectiveness of UV flow disinfection lamps and ozone generators.

The operation and effectiveness of the UVC LED light have been tested in the laboratory of the Department of Biotechnology and Food Microbiology at the University of Life Sciences in Wrocław, on the following pathogens:

- ✓ P22 ATCC 97540 bacterial virus
- ✓ FELIX01 DSM 18524 bacterial virus
- ✓ BAA 2469 (NDM) gram-negative bacteria Eschrichia coli
- ✓ ATCC 140288 gram-negative bacteria Salmonella typhimurium
- ✓ ATCC 43300 (MRSA) gram-positive bacteria Staphylococcus aureus



As a result of irradiation of samples with the above pathogens at the concentration of  $1-2 \times 10^5$  cfu / ml, from a distance of 2.5 meters (time from 20 minutes to 120 minutes), they contributed to their reduction by 99.5% - 100%.



**nanoscan**

NanoScan Sp. z o.o.  
ul. Kwiatowa 15, 16-001 Ignatki

NIP 9662161965  
Regon 521742511

Tel.: +48 85 667 10 67

Email: [biuro@tytancoat.com](mailto:biuro@tytancoat.com)  
[tytan@tytancoat.com](mailto:tytan@tytancoat.com)